Instructions for the Use and Care of Your
Metro "Vac 'N' Blo"

1. Attach three-conductor extension cord to power supply. Insert male plug into electrical outlet.

2. Start appliance by pushing the toggle switch from left to right.

3. HOSE: When use of hose is desired, connect to suction end of the "Vac 'N' Blo" for cleaning purposes, to exhaust end for blowing purposes.

4. EXTENSION WANDS: Reach those inaccessible spots. Eliminate bending to clean low areas and under furniture . . . stretching to reach high areas.

5. "PIK-ALL" NOZZLE: Cleans stairs, upholstery, furniture, draperies, mattresses, pillows, automobile interiors, mobile homes and boat interiors.

6. CREVICE TOOL: Cleans those hard-to-reach tight spots such as radiators, pianos, bedsprings, baseboards, around the cushions of upholstered furniture, moldings, etc. Can be used for vacuuming and blowing purposes.

7. POWERIZER/AIR MAXIMIZER: This tapered accessory concentrates and maximizes air flow for both vacuuming and blowing purposes.

IMPORTANT

To use as a blower, release clamps and remove front end cap, cloth bag and fiberglass filter.

TO INFLATE INFLATABLES

Inflator Adaptor: When inflating air mattresses, boats, rafts with large valves, place blowing (exhaust) end into or against valve until inflatable is filled. When inflatable inflates with small valves, place tapered adaptor on to blowing (exhaust) end, snap on to "push button" locking device. When flexibility is needed, attach flexible hose to exhaust/blowing end.

CAUTION

1. If your "Vac 'N' Blo" has suction but does not clean when hose is attached, remove hose from suction end and place on to blower end. Blow out the hose . . . sometimes it might be clogged. Empty cloth bag after each cleaning.

Fiberglass filter should be replaced three times a year.

Mode d'Emploi du Metro "Vac 'N' Blo"

1. Attachez le cordon prolongateur à trois broches au courant électrique. Insérez la fiche mâle dans la prise de courant.

2. Pour commencer, poussez l'interrupteur à culbuteur de gauche à droite.

3. LE TUYAU FLEXIBLE: Mettez le tuyau flexible en contact avec le suceur. Pour souffler, mettez-le en contact avec l'échappement.

4. LES RALLONGES: Pour nettoyer partout, employez les rallonges au lieu de se courber et de se tendre.

5. LE SUCEUR PIK-ALL: Pour nettoyer les escaliers, les meubles, la moulure, les rideaux, les oreillers, les matelas et l'interieur des voitures et des bateaux, employez le suceur Pik-All.

6. LE SUCEUR PLAT: Pour nettoyer les radiateurs, les pianos, les lits, les coussins, etc. pour épousseter et souffler.

7. LE RÉGULATEUR D'ASPIRATION: Cet accessoire concentre et porte au maximum la circulation d'air.

IMPORTANT

Pour souffler, déclenchez les serre-joints et enlevez le capot, le sac et le filtre

LES GONFLABLES

L'Adapteur: Pour gonfler les matelas pneumatiques, les bateaux et les radeaux, mettez l'échappement dans la valve. Quand la valve est petite, mettez l'adapteur effilé sur le bout soufflant (l'échappement) et attachez - le au bouton - poussoir de la gâchette Pour la flexibilité, attachez le tuyau flexible au bout soufflant.

AVERTISSEMENT

1. Si votre "Vac 'N' Blo" a de l'aspiration mais ne nettoie pas quand vous attachez le tuyau, enlevez - le du bout d'aspiration et attachez - le au bout soufflant. Le tuyau peut être obstrué. Videz le sac après chaque nettoyage.

Le filtre à fibres de verre doit être remplacé trois fois par an.